

Quality is not an act,
it is a habit...

The Nightingale ShermanHd™
is 69% Recyclable

Quality is not an act,
it is a habit...

The Nightingale ShermanHd™
is 69% Recyclable

Quality is not an act,
it is a habit...

The Nightingale ShermanHd™
is 69% Recyclable

How To Care For Your ShermanHD™

With regular care and maintenance, your ShermanHD™ will provide you with superior performance and satisfaction. To maintain the quality of your Nightingale product, please follow the cleaning and maintenance procedures outlined here.

Mechanism

Oil sparingly moving parts once a year with light machine oil. NOTE: to prevent dripping, avoid over lubrication which may cause damage to surrounding surfaces.

Fabric

Clean with mild detergent and water applied with a damp clean cloth or sponge. Rinse with water. Never use hot water and avoid scrubbing. Use gentle movements.

Plastic parts

Clean with mild detergent and water. Do not use abrasives or excessive amounts of cleaner.

Frame

Powder coat frames can be cleaned by wiping with a damp cloth and any mild detergent.

* The instruction for the care and maintenance of Nightingale Products are provided to you as a service. No warranty is implied since results may vary.



Nightingale Office Chairs
Toll-Free Phone: 1.800.363.8954
Fax: 1.800.637.6784
Website: www.nightingalechairs.com
Email: info@nightingalechairs.com

User Guide Instructions



ShermanHD™



MODEL HD9000 Series



Congratulations On Purchasing Nightingale's ShermanHD™

Please read and understand this user guide with instructions before operating this office chair.



How To Use and Adjust My ShermanHD™



A. Tension Knob
Turn clockwise to increase tension, turn counter-clockwise to decrease tension.



B. Arm Height Adjustment
Turn knob clockwise to raise, counter-clockwise to lower.



C. Seat Depth Adjustment
Loosen hand wheel (do not remove) and slide back to desired position, then re-tighten hand wheel.



D. Lumbar Support
Built into back for increased comfort and support.



E. Fold Away Arms
Lift arm at arm pad and push backward to move arm out of way. To put back lift arm and drop back onto bracket.



F. Seat Height Adjustment
To lower, lift paddle while seated. To raise lift paddle with weight off seat.



G. Arm Width Adjustment
To adjust arm width, loosen hand wheel (do not remove) move arm to desired position and re-tighten hand wheel.



H. Infinite Position Tilt Lock
To lock chair in position, push paddle down. To allow free movement, pull paddle up.



I. Adjustable Foot Ring
To loosen, turn wheel counter-clockwise and move ring to desired height, turn wheel clockwise to tighten.



PASS IT ON!

Our customers often tell us their friends stop and ask about their **ShermanHD™** If this happens to you, please give your friend this card so they can learn more about our chairs.

Nightingalechairs.com
1.800.363.8954
info@nightingalechairs.com

PASS IT ON!

Our customers often tell us their friends stop and ask about their **ShermanHD™** If this happens to you, please give your friend this card so they can learn more about our chairs.

Nightingalechairs.com
1.800.363.8954
info@nightingalechairs.com

PASS IT ON!

Our customers often tell us their friends stop and ask about their **ShermanHD™** If this happens to you, please give your friend this card so they can learn more about our chairs.

Nightingalechairs.com
1.800.363.8954
info@nightingalechairs.com