TONIK

Nightingale

User Handbook



1100 Series

nightingalechairs.com

User Guide Adjustments





Nightingale Corp. T 1.800.363.8954 F 1.800.637.6784 www.nightingalechairs.com info@nightingalechairs.com



ARMS
Fully upholstered arms



B TILT LOCK
To lock in upright position, push lever in towards seat. To unlock, pull lever out



© TENSION KNOB

Turn knob clockwise to increase tension, turn counter-clockwise to decrease tension.



D PNEUMATIC HEIGHT ADJUSTMENT

To lower, turn the lever while seated. To raise, turn lever with your weight off the seat.