

# STOOL

User Handbook

 **Nightingale**



**1000 Series**

[nightingalechairs.com](http://nightingalechairs.com)

# Congratulations, this Stool is yours.

Please read and understand the user  
adjustment guide before operating the chair.



1000WB



1000



1000WB



1000WB-DS

# Using & Adjusting Your Stool



A

## Pneumatic Height Adjustment

To lower, lift the lever while seated. To raise, lift lever with your weight off the seat.



B

## Adjustable Foot Ring (Optional)

To loosen, turn wheel counter-clockwise and move ring to desired height. Turn wheel clockwise to tighten.

# Care Instructions

With regular care and maintenance, your Stool will provide many years of superior performance and satisfaction. To maintain the quality of your Nightingale product, please follow the cleaning instructions outlined here.

## Mechanism

Oil sparingly moving parts once a year with light machine oil. NOTE: to prevent dripping, avoid over lubrication which may cause damage to surrounding surfaces.

## Fabric

Clean with mild detergent and water applied with a clean damp cloth or sponge. Rinse with a damp (water) cloth and let dry. Never use hot water and avoid scrubbing. Use gentle movements.

## Plastic Parts

To clean, spray with a mild detergent and wipe off using a damp (water) cloth. Do not use abrasives or excessive amounts of cleaner.

## Frame

Powder coat frames can be cleaned by wiping with a damp cloth and any mild detergent.

\*The instruction for the care and maintenance of Nightingale Products are provided to you as a service. No warranty is implied since results may vary.

FOR MORE INFORMATION, PLEASE VISIT

**[nightingalechairs.com](http://nightingalechairs.com)**



**Nightingale Corp.**  
T 1.800.363.8954  
F 1.800.637.6784  
[nightingalechairs.com](http://nightingalechairs.com)  
[info@nightingalechairs.com](mailto:info@nightingalechairs.com)



RECYCLABLE